

USB-POWERED POLAR FLEECE ELECTRIC HEATED VEST

DHV06P

➤ User Guide

EN USB-POWERED POLAR FLEECE ELECTRIC HEATED VEST --- 01
USER GUIDE

DE USB POLAR FLEECE ELEKTRISCH BEHEIZTE WESTE ----- 04
BETRIEBSANLEITUNG

JP ポーラーフリース電熱ベストUSB給電式 ----- 07
取り扱い説明書

SPECIFICATIONS

Input	5V / 2A
Rated Wattage	9.5W
Three Heating Levels	High (Red light), Medium (White light), Low (Blue light)
Material	Polar Fleece

PACKAGE INCLUDES

- 1 x Heated Vest
- 1 x Laundry Bag
- 1 x User Manual

INSTRUCTIONS

※ Please use a portable battery pack with 2 A or 2.4 A USB output to power up this vest. ※

1. Unzip the inner pocket and take out the USB cable.
2. Insert the USB cable into the port of a portable charger. Then press the Power Button on the portable charger. The switch will cycle through Red, White, and Blue briefly.
3. Press and hold the switch for 2 seconds and it turns red. The vest begins to heat at a high level.
4. Press the switch and it will turn white. The vest adjusts to the medium level.
5. Press the switch again and it will turn blue. The vest adjusts to the low level.
6. Press and hold the thermal switch for 2 seconds to stop the vest from heating.

CARE AND MAINTENANCE

1. Take out the portable charger. Hand wash the vest with neutral detergent. Do not clean the vest by rubbing or kneading roughly. Drip dry the vest in a cool, well-ventilated place before the next use.
2. Please put the vest in a laundry bag to extend its lifetime if you prefer machine wash.

WARNING

1. Do not plug the vest into your portable charger if you do not plan to use it for a long time.
2. Do not hand wash the vest in hot water or with strong acidic detergent.
3. Do not wear the vest when it is wet. Once the vest is wet by rain or splashes, shut off the power and stop using the vest immediately.
4. The heated vest's runtime varies with your portable charger's capacity.

WARRANTY

- Dr.Prepare products are covered by a 12-month limited warranty from the original purchase date. If any problems occur, please contact our support team.
- We only provide after-sales services for products that are sold by Dr.Prepare or retailers and distributors authorized by Dr.Prepare. If you have purchased your unit from other channels, please contact your seller for more information about return and warranty.

CUSTOMER SUPPORT

- If you have any questions or concerns, please send us an email at support@drprepare.com

USB POLAR FLEECE ELEKTRISCH BEHEIZTE WESTE

DHV06P

➤ Betriebsanleitung

SPEZIFIKATION

Input	5V/2A
Nennleistung	9.5W
3 Heizstufen	Hoch (Rot Licht), Mittel (Weiß Licht), Niedrig (Blau Licht)
Material	Polar Fleece

PAKET

- 1 x Beheizte Weste
- 1 x Aufbewahrungstasche
- 1 x Bedienungsanleitung

ANWEISUNGEN

※ Bitte verwenden Sie einen tragbaren Powerbank mit 2 A oder 2,4 A USB-Ausgang, um diese Weste mit Strom zu versorgen. ※

1. Nehmen Sie das USB-Kabel heraus.
2. Stecken Sie das USB-Kabel in den Anschluss eines tragbaren Powerbank. Drücken Sie dann die Power-Taste am tragbaren Powerbank. Der Schalter wechselt kurz durch Rot, Weiß und Blau.
3. Halten Sie den Schalter 2 Sekunden lang gedrückt und er wird rot. Die Weste beginnt auf hohem Stufen zu heizen.
4. Drücken Sie den Schalter und er wird weiß. Die Weste beginnt auf mittlerem Stufen zu heizen.
5. Drücken Sie den Schalter erneut und er wird blau. Die Weste beginnt auf niedrigen Stufen zu heizen.
6. Halten Sie wieder den schalter 2 Sekunden lang gedrückt, um das Heizen der Weste zu stoppen.