

LED CHRISTMAS PROJECTOR (SNOW EFFECTS)

Model: DPL-0CL01



WARNINGS

- 1. Please make sure the power is off before installation.
- 2. Please do not disassemble or alter the product.
- 3 Please follow the instructions from our user manual to use this projector.
- 4. Please use the supplied power adapter only.
- 5. We advise you not to use the projector continuously over 4 hours each time.

SPECIFICATIONS

Input Voltage	AC100V- 240V
Output Voltage	14V / 300mA
Light Source	5W LED
Ingress Protection Rating	IP65
Length of Power Cord	16.4ft / 5m

ACCESSORIES

Projector * 1 Ground Stake * 1

Power Adapter * 1 User Manual * 1

Screws * 2

Round Base * 1

Quick-Release Knob & Hex Nut * 1



Power Adapter



Ground Stake



Projector





Round Base

Screws

Quick-Release Knob & Hex Nut

ASSEMBLY INSTRUCTIONS

- Attach the bracket to the projector with two screws (see fig. 1).
- Use the hex nut and knob to fasten the bracket under the projector and the stake (see fig. 1).
- Connect the 2-pin power cord with the included power adapter. Fasten two parts to ensure secure connection.



MAINTENANCE

- Please clean the lamp regularly to ensure performance of the projector. Make sure the power is cut off before maintenance.
- To avoid any damages to the projector, please do not use chemical cleaning solvent for routine maintenance.